

Código				Tipo cojinete Eje					
2-0028	80	300	34	—	106x86	86/80x60	8	124	64
2-0029	100	400	34	—	106x86	86/80x60	8	140	81
2-0030	125	600	44	—	139x110	110x84/98x66	10	164	115
2-0031	150	750	45	—	139x110	110x84/98x66	10	188	133
2-2894	150	750	45	●●	139x110	110x84/98x66	10	188	133
2-0221	200	800	45	—	139x110	110x84/98x66	10	251	155
2-1574	200	800	45	●●	139x110	110x84/98x66	10	251	155

Código				Tipo cojinete Eje					
2-0032	80	300	34	—	106x86	80x60	8	124	
2-0033	100	400	34	—	106x86	80x60	8	140	
2-0034	125	600	44	—	136x116	110x84/98x66	10	164	
2-0035	150	750	45	—	136x116	110x84/98x66	10	188	
2-2895	150	750	45	●●	136x116	110x84/98x66	10	188	
2-0222	200	800	45	—	136x116	110x84/98x66	10	251	
2-2897	200	800	45	●●	136x116	110x84/98x66	10	251	

Código				Tipo cojinete Eje					
2-1628	80	300	34	—	106x86	86/80x60	8	124	64
2-1629	100	400	34	—	106x86	86/80x60	8	140	81
2-1630	125	600	44	—	139x110	110x84/98x66	10	164	115
2-1639	150	750	45	—	139x110	110x84/98x66	10	188	133
2-2896	150	750	45	●●	139x110	110x84/98x66	10	188	133
2-0960	200	800	45	—	139x110	110x84/98x66	10	251	155
2-2898	200	800	45	●●	139x110	110x84/98x66	10	251	155