

Código				Tipo cojinete Eje					
2-3077	80	100	34	=====	95X80	80X60	8	108	71
2-3078	100	110	34	=====	95X80	80X60	8	127	80
2-3079	125	120	35	=====	95X80	80X60	8	155	88

Código				Tipo cojinete Eje					
2-3080	80	100	34	=====	100X80	80X60	8	108	
2-3081	100	110	34	=====	100X80	80X60	8	127	
2-3082	125	120	35	=====	100X80	80X60	8	155	

Código				Tipo cojinete Eje					
2-3083	80	100	34	=====	95X80	80X60	8	108	71
2-3084	100	110	34	=====	95X80	80X60	8	127	80
2-3085	125	120	35	=====	95X80	80X60	8	155	88