

RUEDAS BH-BP

Código				Tipo cojinete Eje					
1-0166	60	50	24	—	70x55	54x38	6	88	62
2-1911	80	70	22	—	70x55	54x38	6	110	77
1-0221	100	80	25	—	70x55	54x38	6	132	90
2-1432	125	125	35	—	80x70	60x50	8	159	96

Código				Tipo cojinete Eje					
2-2457	80	70	22	—	75x66	54x38	6	110	
2-2458	100	80	25	—	75x66	54x38	6	132	

Código				Tipo cojinete Eje					
2-1912	80	70	22	—	70x55	54x38	6	110	77
2-1915	100	80	25	—	70x55	54x38	6	132	90
2-1917	125	125	35	—	80x70	60x50	8	159	96