

RUEDAS BH-BP

Código				Tipo cojinete Eje					
1-0174	60	50	24	_____			10	85	62
2-1913	80	70	22	_____			10	108	77
1-0222	100	80	25	_____			10	129	90
2-1433	125	125	35	_____			10	156	96

Código				Tipo cojinete Eje					
2-1914	80	70	22	_____			10	108	77
2-1916	100	80	25	_____			10	129	90
2-1918	125	125	35	_____			10	156	96